

# ASSEMBLY

A9235 PRO SPEAK EVO  
FOR FREERIDE X



Remove the inner linings as indicated in the helmet user manual.



Place the right speaker (R) in its seat on the velcro.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Place the microphone base under the chinstrap.

**WARNING** check that the triangle on the microphone is facing the mouth

# ASSEMBLY

A9235 PRO SPEAK EVO  
FOR FREERIDE X



Place the BT controller in the designated slot on the back of the inner shell.



House the cables behind the rear cushion.



Place the USB port between the liner and EPS shell.



Fit the keypad on the left side (helmet on), approximately 10 mm from the lower edge of the shell using the provided adhesive. Make sure that there is full contact surface between the adhesive keypad and the outer shell.