





Remove the cheekpads as indicated in the communicator's instruction manual.



Place the right speaker (R) in its seat after applying the adhesive round shaped Velcro included in the package.



Repeat the operations performed for the right (R) speaker for positioning the left (L).



Place the microphone with wire on chin cover after applying the adhesive Velcro included in the package.







House the speaker's cable (connecting the right speaker to the left) behind the rear cushion.



Place the BT controller in the designated slot on the back of the inner shell.



Place the USB socket between the removable cheekpads and the rear cushion.



Before assembling the cheekpads, pass the remote control with its flat cable in the slot in the left cheekpad's pp plate.







Fit the keypad on the left side (helmet on), approximately 15 mm from the lower edge of the shell using the provided adhesive. Make sure that there is full contact surface between the adhesive keypad and the outer shell.

